

CELLBUSTERS - ZONE PROTECTOR  
CB-ZP-AMT9900 SERIES

# QUICK START GUIDE



**CELLBUSTERS** 

# 1 Check Package Contents

Verify the package includes the following contents:

- *Cellbusters Zone Protector™* series appliance
- Ethernet cable
- Power Adapter



# 2 Connect the Rechargeable Battery Pack

## Connecting the rechargeable battery pack

 Ensure the power adapter and POE power are fully disconnected from the *Zone Protector™* before connecting the rechargeable battery

- Remove the battery cover at the rear of the *Zone Protector™* to reveal the rechargeable battery compartment and battery pack socket.
- Connect the battery pack to the socket inside the battery compartment.
- Replace the battery pack cover.
- To engage the battery, the *Battery* switch at the rear of the *Zone Protector™* will need to be moved to the *On Position*.



# 3 Connect Devices

- Connect an Ethernet cable from the Ethernet(POE) port on the *Zone Protector™* to the Ethernet port on the computer
- Plug the Power adapter into a grounded power outlet (100 - 240V AC); and then from the power adapter connect to the 5V DC power port on the rear of the *Zone Protector™*.



# 4 Run the Setup Wizard

- With the computer connected to the *Zone Protector™* open a web browser and navigate to <http://192.168.1.48> (the default IP address of the *Zone Protector™* appliance). If the computer cannot connect to the *Zone Protector™* you may need to restart the *Zone Protector™* or the computer.
- When successfully connected your browser will prompt you with a username and password login box. The default username is *admin* and the default password is *admin*.
- Once logged in click on the *Setup Wizard* which guides you through the basic setup of the *Zone Protector™* appliance.

 You may need to restart your computer after the *Setup Wizard* is complete.

The *Zone Protector™* issues an IP address to the computer (using an internal DHCP server). It is advisable that you disable this feature via the *Zone Protector* dashboard before adding the *Zone Protector™* to your network.

# 5 Register

- Register the *Zone Protector™* online by following the instructions at <http://www.cellbusters.com/register>

*The Zone Protector™ serial number is found on the appliance.*

## Need Help?

For the latest knowledge base documentation, support forum and firmware downloads visit <http://support.cellbusters.com>

 Registration must be completed to avail of the standard warranty, firmware updates and web support



## Safety Information

### Mounting the Zone Protector™

Mount in a location away from direct sunlight and sources of heat. Maximum ambient room temperature is 104°F (40°C) Route cables away from power lines, florescent lighting fixtures, and sources of noise.

Ensure that no water or excessive moisture can enter the unit.

Allow unrestricted airflow around the unit and through its vents on the side of the unit. A minimum of 1 inch (25.44mm) clearance is recommended.

## **Safety Information continued**

Consideration must be given to the connection of the equipment to the supply circuit and the effect of overloading the circuits has minimal impact on overcurrent protection and supply wiring. Appropriate consideration of the equipment nameplate ratings must be used when addressing this concern.

### **Rechargeable Battery Warning**

The Nickel Metal Hydride rechargeable battery should only be replaced with *Cellbusters* part number **CBZP-BP9600** only. All power sources must be disconnected before fitting or replacing the rechargeable battery. The rechargeable battery should be removed from the **Zone Protector™** when not in use. It is recommended that the rechargeable battery is replaced annually.

If for any reason the rechargeable battery should be disposed of. Do so following the battery's manufacturer instructions.

### **Cable connections**

All Ethernet cables are designed for intra-building connection to other equipment. Do not connect these ports directly to communications wiring or other wiring that exits the building where the **Zone Protector™** is located.

### **Power Supply Information**

To order a replacement power supply please contact *Cellbusters* for power supply replacement part number **CBZP-PSU**.

The **Zone Protector™** should only be used with a UL listed power supply marked "I.T.E LPS", with an output rated 5V DC, minimum 1.5A. Tma:  
Minimum 40°C



**CELLBUSTERS** 

*Copyright © 2011 Cellbusters Inc. All rights reserved.*

**WWW.CELLBUSTERS.COM**

**TEL: 866-402-3977 (USA TOLL FREE)**